



Typical RGB Control


Typical C-Bus/DMX to RGB



Typical C-Bus/O-DV to RGB



Typical C-Bus/DALI to RGB



The DALI Ballasts are to be addressed with DALI commissioning software connected directly to the DALI Bus, not via the C-Bus commissioning software. This software, and any associated hardware, is best provided by the ballast manufacturer thus preventing warranty disputes in the event of incorrect ballast operation.